


Set Up for eTrex Touch 25

- Install batteries
 - Twist small **D ring** on back to open
 - Make sure the batteries are inserted the correct way!




Set Up for eTrex Touch 25

- Turn on and configure unit
 - Press and hold **Power Key** for about 3 sec – button on upper right side
 - Unit will take 20+ seconds to turn on.



Set Up for eTrex Touch 25


- Battery Type
 - Press **Power Key** and then tap **Setup**
 - Tap **System** and then tap **Battery Type**
 - Tap **Alkaline**
 - Tap back arrow in lower left



Battery Indicator

Power Key


Setup



Setup Menu

Battery Type

Back Arrow




Set Up for eTrex Touch 25

- **Battery Save**
 - Press **Power Key** and then tap **Setup**
 - Tap **Display**
 - Tap **Backlight Timeout** and select **2 minutes**
 - Tap **Battery Save** and then **OK**


Set Up for eTrex Touch 25

- Position Format
 - Press **Power Key**
 - Tap **Setup**
 - Scroll to **Position Format** and tap
 - Tap Position Format
 - Scroll UP to **hddd.ddddd** and tap
 - Make sure **Map Datum** and **Map Spheroid** are **WGS 84**
 - Tap back arrow in lower left



Set Up for eTrex Touch 25

- Units
 - On setup menu scroll to **Units** and tap
 - Tap **Speed/Distance**
 - Select **Metric**
 - **Back arrow**
 - Tap **Vertical Speed**
 - Select **Meter (m/min)**



Set Up for eTrex Touch 25

- Compass calibration
 - On setup menu scroll to **Heading** and tap
 - Tap **Calibrate Compass**
 - **Follow screen directions carefully**
 - **Tip:** Move the unit slowly or you will get error message!!

Mark (set) Waypoint

- Press **Power Key**
- Tap **Mark Waypoint**
- Tap **number field at top** – eg 002
- Use touch keyboard to enter name – can toggle to numbers
- Tap the **Check** in lower right to **Save** name



Power Key

Mark
Waypoint



Key Pad

Toggle

Check

Mark (set) Waypoint – Cont'

- tap **Lat-Lon field** to edit
- Edit **Numbers** for **Latitude** and **Longitude** using touch keypad
 - Note the scroll **left-right arrows**
 - Make sure Latitude is **N** (north)
 - Make sure Longitude is **W** (west)
- Check your numbers!
- When done tap the **Check** in lower right to save lat-lon
- Tap **Check** in lower center to **save waypoint!**

Mark (set) Waypoint – Cont'




Navigate to Way Point with eTrex Touch 25

- Turn on unit with **Power Key** – wait for unit to start operating
- Press Power Key and scroll to **Satellite**, tap and ensure unit has several satellites with good signal (**Optional**)


Navigate to Way Point with eTrex Touch 25 cont'

- Tap Power Key and tap **Waypoint Manager**
- Scroll or spell search for way point and tap
- Tap **Bar Menu** in lower right and select **View Map**




Waypoints

To Spell Search



View Map

Menu



Navigate to Way Point with eTrex Touch 25 cont'

- On map tap **Go** and wait for calculation to finish




Navigate to Way Point with eTrex Touch 25 cont'

Press Power Key and scroll to **Compass**, and tap



Navigate to Way Point with eTrex Touch 25 cont'

Note: compass is not accurate until you move



**Distance to
Waypoint**

Compass


Navigate to Way Point with eTrex Touch 25 cont'

- Follow the arrow on the compass until you are at **0 meters or see Stake**
 - Need to move some distance for compass to work
 - **Note:** Do not expect perfect reproducibility in distance: you may need to hunt for the stake.
 - **Important Note:** As you approach the waypoint the unit will say '**Arriving at waypoint**'. You are **not** at the way point. Tap **OK** to continue to the waypoint. The actual distance at which this message appears depends on your speed.


Navigate to Next Way Point with eTrex Touch 25

- To go to the **next waypoint**.
- On **Compass**, pull up menu from the bottom of screen
- Tap the **Menu Bars** on **lower right** and tap **Stop Navigating**
- Make sure the **Compass Display** shows no numbers
- **If you do not follow this procedure you may not be able to navigate to the next way point.**

Navigate to Next Way Point with eTrex Touch 25 cont'




**Pull up
menu**



**Stop
Navigation**

**Menu
Bars**



Pitfall with eTrex Touch 25

- In **Battery Save** mode, screen goes dark
 - Press the **Power Key**
- If **Compass** does not display distance to destination in **metric**
 - Tap the upper right number on the display
 - Tap **Speed and dist.**
- **Carry spare batteries!**
- Make sure you are using the correct coordinate system – **hddd.ddddd** and **WGS84!**

Trouble shooting

- IF Screen shows **RESTORE DEFAULTS**, tap **back arrow**
 - **Restore Defaults** are factory settings. Change to our survey settings in **SET UP**
- IF dist to dest. and compass arrow function do not work: Set up/Routing/ Activity= choose Direct Routing
Does not matter if Lock on Road is on or off.
- Maps: enable Worldwide DEM on, (others no- for Garmin demo purposes)
- Ignore the following message if it comes up: “This route may take a long time to calculate. Consider Adding via points.”